



5 Steps To Program Your HomeLink® System

Note: Some vehicles may require the ignition be turned on or the vehicle actually running to program the Homelink® transceiver.

To program a rolling code compatible Homelink® system, please follow these steps.

- 1.** Press and hold the two outside buttons on the Homelink® system until the LED starts to blink, release buttons
- 2.** Press and hold the desired Homelink® button and the transmit button on your rolling code transmitter at the same time until the Homelink® LED changes from a slow blink to a rapid blink. (Your Homelink® system is now programmed)
- 3.** Locate the learn code button on your garage door opener. (These are located under the light cover or on the rear panel depending on model)
- 4.** Press the learn code button on the garage door opener, a red LED will start to blink. (You will have 30 seconds to complete programming)
- 5.** While the LED on the garage door opener is blinking, return to the vehicle and press the pre-programmed Homelink® button 4 times. (Or until the garage door operates).

If you have problems with the Homelink® system please call 1-800-355-3515 or their website at <http://www.homelink.com/home.php>

Homelink® is a registered trademark of Johnson Controls, Inc.